

Tahoe bench with backrest assembly

TBC20, TBN20 bench with backrest.

▲ Leg assembly L&R 1 each



Back panel 1 piece



Seat panel 1 piece



Seat brace 1 piece



TBEI M8x10 screw 12 pieces



TBEI M6x20 screw 12 pieces



Attach seat brace to bench

Attach seat brace (D) to bench using twelve M6x20 screws (F).



Unpack and prepare your components

Unpack your bench with backrest. Place pieces on a soft surface to protect the finish.

Two-person assembly is recommended.



Attach back panel to leg assemblies

Stand leg assemblies (A) on feet, parallel to each other, supported in the vertical position. Attach back panel (B) to leg assemblies using three M8x10 screws (**E**) per side.



Attach seat panel to leg assemblies

Attach seat panel (C) to leg assemblies using three M8x10 screws (**E**) per side.





