

Reset

Control Mechanisms:

- Task Chair #352
- Task Stool #11DR/#11XDR



Reset Light Task Chair #352



Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our Reset Control
Online User Guide

Light Task Stool #11DR



Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Foot Ring #11DR & #11XDR

Type: Footrest

Press down on the plastic inner hub and lift the foot ring up to unlock. Adjust to desired position. To lock, press down on the outer foot rest until hub is in locked position.



< Watch this Control
Online User Guide



Watch our Foot Ring >
Online User Guide