

# Genie<sup>®</sup>

## Control Mechanisms:

- Basic Conference #25C
- Basic Conference & Seat Depth #26C
- Auto-Adjust Body Balance #74C
- Quick Adjust Advanced Synchro #67C
- Stool: Auto-Adjust Body Balance #35C

## Adjustable Arms:

- Basic Adjustable Arms #38A
- Roll Back Arms #39A
- Adjustable Arms #51A/#52A/#53A

## Adjustable Lumbar:

- Adjustable Lumbar #LS1



# Basic Conference #25C



## Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

## Back/Recline Tension

Type: Rotatable knob

Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension. You can use your right or left hand based on your own comfort.

## Single Position Back Lock

Type: Pull paddle

Use the same paddle you used for the seat height adjustment. To lock the chair in an upright position, shift your weight forward until the chair is in an upright position, then push lever in. To rock (free float) shift your weight forward and pull the lever out.



< Watch our 25C  
Online User Guide

# Basic Conference & Seat Depth #26C



## Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

## Back/Recline Tension

Type: Rotatable knob

Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension. You can use your right or left hand based on your own comfort.

## Single Position Back Lock

Type: Pull paddle

Use the same paddle you used for the seat height adjustment. To lock the chair in an upright position, shift your weight forward until the chair is in an upright position, then push lever in. To rock (free float) shift your weight forward and pull the lever out.

## Seat Depth #12SS

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.



< Watch our 26C  
Online User Guide

# Auto-Adjust Body Balance #74C



## 4-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

## Optional Seat Depth #12SS

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

## Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 74C  
Online User Guide



Watch our 74C-12SS >  
Online User Guide

# Quick Adjust Advanced Synchro #67C



## Back Tension

Type: Turn dial

Rotate knob right to increase tilt tension.  
Rotate knob left to decrease tilt tension.

## Optional Seat Depth #SS

Type: Pull paddle

Push down on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

## 5-Position Tilt Limiter

Type: Turn dial

To recline more, turn the dial right.  
To recline less, turn the dial left.

## Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

## Optional Forward Tilt #FT

Type: Pull paddle

Push the paddle in the down position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned on. To turn off the forward tilt feature, lift the paddle in the up position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned off.



< Watch our 67C-SS  
Online User Guide



Watch our 67C-SS-FT >  
Online User Guide

# Stool: Auto-Adjust Body Balance #35C



### 3-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

### Foot Ring #11DR & #11XDR

Type: Footrest

Press down on the plastic inner hub and lift the foot ring up to unlock. Adjust to desired position. To lock, press down on the outer foot rest until hub is in locked position.

### Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 35C  
Online User Guide



Watch our Foot Ring >  
Online User Guide

# Basic Adjustable Arms #38A/#38AG



## Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

## Optional Arm Width (In/Out)

Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.



< Watch our 38A/38AG  
Online User Guide

# Roll Back Arms #39A



### Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

### Roll Back Feature

Type: Button

While pressing and holding the small button toward the top front on the silver circle, grasp the arm and roll back to horizontal position where arm is parallel with the floor. Repeat to lift back to upright for use as an armrest.



< Watch our 39A  
Online User Guide

# Adjustable Arms #51A/#51AG/#52A/#53A



## Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

## Optional Armrest Rotation

Type: Armrest

Grasp armrest and turn left or right to rotate a max of 15° each way.

## Optional Arm Width (In/Out)

Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.

## Optional Armrest Back/Forth

Type: Armrest

Grasp armrest & slide it forward or back to desire position. Armrest slides forward a max of 1.5".



< Watch our 51A/51AG/52A/53A  
Online User Guide

# Adjustable Lumbar #LS1



**Vertical Lumbar Position**  
Type: Handles

Grasp the lumbar support with both hands and lift the lumbar support up or down.



< Watch our LS1  
Online User Guide