

Oslo

Control Mechanisms:

- Auto-Adjust Body Balance #74C
- Quick Adjust Advanced Synchro #67C
- Synchro #9CH
- Synchro & Seat Depth #10CH

Adjustable Arms:

- Adjustable Arms #51A/#53A

Adjustable Headrest:

- Integrated Adjustable Headrest

Adjustable Backrest:

- Integrated Ratchet Back



Auto-Adjust Body Balance #74C



4-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

Optional Seat Depth #12SS

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 74C
Online User Guide



Watch our 74C-12SS >
Online User Guide

Quick Adjust Advanced Synchro #67C



Back Tension

Type: Turn dial

Rotate knob right to increase tilt tension.
Rotate knob left to decrease tilt tension.

Optional Seat Depth #SS

Type: Pull paddle

Push down on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

5-Position Tilt Limiter

Type: Turn dial

To recline more, turn the dial right.
To recline less, turn the dial left.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Optional Forward Tilt #FT

Type: Pull paddle

Push the paddle in the down position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned on. To turn off the forward tilt feature, lift the paddle in the up position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned off.



< Watch our 67C-SS
Online User Guide



Watch our 67C-SS-FT >
Online User Guide

Synchro #9CH



Back/Recline Tension

Type: Rotatable knob

Pull paddle knob out. Turn right to tighten or left to loosen the back tension



5-Position Back Lock

Type: Rotatable knob

Tilt the seat back to desired angle and twist a quarter turn. To unlock, twist the other way and lean back.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 9CH
Online User Guide

Synchro & Seat Depth #10CH



Back/Recline Tension

Type: Rotatable knob

Pull paddle knob out. Turn right to tighten or left to loosen the back tension



Seat Depth

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

5-Position Back Lock

Type: Rotatable knob

Tilt the seat back to desired angle and twist a quarter turn. To unlock, twist the other way and lean back.



< Watch our 10CH
Online User Guide

Adjustable Arms #51A/#51AG/#52A/#53A



Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Optional Armrest Rotation

Type: Armrest

Grasp armrest and turn left or right to rotate a max of 15° each way.

Optional Arm Width (In/Out)

Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.

Optional Armrest Back/Forth

Type: Armrest

Grasp armrest & slide it forward or back to desire position. Armrest slides forward a max of 1.5".



< Watch our 51A/51AG/52A/53A
Online User Guide

Integrated Adjustable Headrest on Oslo



Position

Type: Headrest

Grasp the headrest on both sides and adjust forward or back to your desired position. The headrest tilts 35° from the starting, upright position.



< Watch our Oslo Headrest
Online User Guide

Oslo Ratchet Back



Height Position

Type: Backrest

Grasp the backrest on both sides and lift it up. At each position, you'll hear a click. As you reach the top position, lift up & then gently drop the backrest down to the lowest starting position. This adjustment allows the backrest to be correctly positioned for differently sized individuals.



< Watch our Executive Ratchet Back
Online User Guide