

Run II

Control Mechanisms:

- Advanced Synchro #81C
- Stool: Advanced Synchro #81C

Adjustable Arms:

- Basic Adjustable Arms #38A
- Roll Back Arms #39A
- Adjustable Arms #51A/#51AG/#53A

Adjustable Lumbar:

- Adjustable Lumbar #LR2/#LR2G



Advanced Synchro #81C



Back Tension

Type: Turn dial

Rotate knob left (forward when seated) to increase tension. Rotate knob right (backward when seated) to decrease tension. Offers 4 tension levels.

4-Position Tilt Limiter

Type: Turn dial

Rotate knob left (forward when seated) to lock in 4 back tilt positions. Rotate knob right (backward when seated) to unlock.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Optional Seat Depth #SS

Type: Pull paddle

Push down on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back. Seat depth locks in 5 positions.

Basic Adjustable Arms #38A/#38AG



Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Optional Arm Width (In/Out)

Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.



< Watch our 38A/38AG
Online User Guide

Roll Back Arms #39A



Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Roll Back Feature

Type: Button

While pressing and holding the small button toward the top front on the silver circle, grasp the arm and roll back to horizontal position where arm is parallel with the floor. Repeat to lift back to upright for use as an armrest.



< Watch our 39A
Online User Guide

Adjustable Arms #51A/#51AG/#52A/#53A



Arm Height (Up/Down) Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Optional Armrest Rotation Type: Armrest

Grasp armrest and turn left or right to rotate a max of 15° each way.

Optional Arm Width (In/Out) Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.

Optional Armrest Back/Forth Type: Armrest

Grasp armrest & slide it forward or back to desire position. Armrest slides forward a max of 1.5".



< Watch our 51A/51AG/52A/53A
Online User Guide

Adjustable Lumbar #LR2/#LR2G



Vertical Lumbar Position

Type: Lever

From the seated position, use your hand to make adjustments by engaging the small, black lumbar adjustment lever. Slide the lever up to move the lumbar support up. Slide the lever down to move the adjustable lumbar support down. You can use your right or left hand based on your own comfort.



< Watch our LR2/LR2G
Online User Guide