

Upholstery

Fabric Upholstery

Vacuum up any excess dirt/spillage with close attention to the seams, area where the seat meets the back and area where the arms meet the seat/back. After, take a lint-free cloth and dip it into any water-based cleaning agent. Scrub gently over the stained area. Repeat if needed. For best results, follow the mill guidelines for your exact textile.

Vinyl Upholstery

Use a bristle brush to gently loosen up the stain. Mix mild soap and warm water together and using a lint-free cloth, damp it a little bit into the mixture and scrub gently wherever the stain is located. Avoid using any detergents as it can cause the vinyl to change color or fade. For best results, follow the mill guidelines for your exact vinyl.

Leather & Faux-Leather Upholstery

Keep leathered upholstery out of direct sunlight so the material doesn't dry out and fade/crack.

Cleaning leather upholstery is easy and can be done in 3 different ways:

- Rubbing alcohol and water.
- Actual leather cleaner you find at a store (always test a small area first).
- Vinegar and linseed oil.

Use a lint-free cloth. Damp it into your cleaning agent and gently scrub the stained area. Use a dry, lint-free cloth to dry the area. Repeat if needed. For best results, follow the mill guidelines for your exact textile.

Groove Fabric

Use a vacuum on a low setting to take all the dirt off. Mix mild soap and warm water together and using a lint-free cloth, damp it a little bit into the mixture. Dab gently where the stain is located. Use a different, dry, lint-free cloth to dry the area. Repeat if needed.

Form Fleece

Remove stains as quickly as possible, before they penetrate the fibres. Remove dried stains with a vacuum cleaner as far as possible. If felt is dirty, wipe it only with a damp cloth.

Mesh

Copper-Infused Mesh

To prevent overall soil, frequently vacuum and lightly brush the best to remove dust and grime buildup. Spot clean with mild soap and water. Infrequent use of a 1:100 bleach to water solution can be used for disinfection of the mesh. The accumulate wet contact time should be limited to a maximum of two hours over the life of the chair. Regular bleach cleaning of this mesh is not recommended.

The following cleaners have been successfully used with Genie Copper Mesh®. Please note, Via Seating does not endorse any of these cleaners. For details, please contact these cleaning product manufacturers directly.

- | | |
|---|---|
| 1. CLOROX® Broad Spectrum Quaternary Disinfectant cleaner | 9. SEALED AIR VIREX II 256 |
| 2. CLOROX® Healthcare bleach germicidal cleaner | 10. SEALED AIR AVERT™ Disinfectant cleaner |
| 3. CLOROX® Dispatch | 11. SEALED AIR Whistle® All Purpose Disinfectant TB cleaner |
| 4. CLOROX® Clean-Up® Disinfectant with Bleach | 12. SEALED AIR EXPOSE® II 256 |
| 5. ECOLAB ASEPTI-WIPE-II | 13. STERIS Coverage® Spray TB |
| 6. GOJO PURELL® Healthcare Surface Disinfectant | 14. STERIS Coverage® Plus NPD |
| 7. METREX Cavicide™ | 15. STERIS Coverage Spray Coverage® Plus Germicidal wipes |
| 8. METREX Envirocide™ | |

Mesh

Mix mild soap and warm water together and using a lint-free cloth, damp it a little bit into the mixture. Dab gently where the stain is located. Use a different, dry, lint-free cloth to dry the area. Repeat if needed.

High-Performance Mesh

Mix mild soap and warm water together and using a lint-free cloth, damp it a little bit into the mixture. Dab gently where the stain is located. Use a different, dry, lint-free cloth to dry the area. Repeat if needed.

Knit Mesh

Vacuum your chair as needed. For stains, mix mild detergent (~10%) and warm water together and using a lint-free cloth, damp it a little bit into the mixture. Dab gently where the stain is located & rinse with warm water. Use a different, dry, lint-free cloth to dry the area. Repeat if needed. Allow to completely dry before use.

Parts

Casters

To get the most out of your casters, it is always good to keep them as clean as possible. Once a month, gently flip your chair over and carefully use tweezers to remove all dirt/hair/debris out of the creases of the caster. Use a lint-free cloth with your preferred cleaning agent and clean the caster thoroughly. Thoroughly dry the caster with another lint-free cloth after.

Backshells

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Materials

Poly/Plastic

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. For tougher stains, you may use distilled vinegar and a lint-free cloth. Repeat if needed.

TPU (Thermoplastic Polyurethane)

To prevent overall soil, frequently vacuum and lightly brush the best to remove dust and grime buildup. Spot clean with mild soap and water. Infrequent use of a 1:10 bleach to water solution can be used for disinfection of the TPU.

Wood

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Laminate

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Metal

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Powder-Coated Metal

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Powder-Coated MDF

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.