

Carmel

Control Mechanisms:

- Basic Conference Tilt #71C
- Dynamic knee-tilt #42C
- Quick Adjust Advanced Synchro #67C

Adjustable Arms:

- Adjustable Arms #51A/#53A

Adjustable Lumbar:

- Adjustable Mechanical Lumbar #12LUM

Adjustable Backrest:


- Ratchet Back #RB

Jury Base:

- Basic Conference Tilt with Jury Base #71C-20JRY



Basic Conference Tilt #71C



Single Position Back Lock

Type: Pull paddle

To lock the chair in an upright position, push the paddle in. To rock (free float), pull the paddle out.

Back/Recline Tension

Type: Rotatable knob

Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension. You can use your right or left hand based on your own comfort.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 71C
Online User Guide

Dynamic Knee-Tilt #42C



Back Tension

Type: Rotatable Lever

Rotate clockwise to increase back tension and counter-clockwise to decrease back tension.

4-Position Back Lock

Type: Pull paddle

To lock the chair in an upright position, turn the paddle up. To rock (free float), turn the paddle down. Lean back to click through the 4 different back positions.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 42C
Online User Guide

Quick Adjust Advanced Synchro #67C



Back Tension

Type: Turn dial

Rotate knob right to increase tilt tension.
Rotate knob left to decrease tilt tension.

Optional Seat Depth #SS

Type: Pull paddle

Push down on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

5-Position Tilt Limiter

Type: Turn dial

To recline more, turn the dial right.
To recline less, turn the dial left.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Optional Forward Tilt #FT

Type: Pull paddle

Push the paddle in the down position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned on. To turn off the forward tilt feature, lift the paddle in the up position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned off.



< Watch our 67C-SS
Online User Guide



Watch our 67C-SS-FT >
Online User Guide

Adjustable Arms #51A/#51AG/#52A/#53A



Arm Height (Up/Down) Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Optional Armrest Rotation Type: Armrest

Grasp armrest and turn left or right to rotate a max of 15° each way.

Optional Arm Width (In/Out) Type: Switch

Rotate the switch located beneath the arm forward. Use your hand to grasp the arm and adjust it out to your desired width away from seat. Each arm adjusts separately. When finished making adjustments, rotate the switch back to its original position.

Optional Armrest Back/Forth Type: Armrest

Grasp armrest & slide it forward or back to desire position. Armrest slides forward a max of 1.5".



< Watch our 51A/51AG/52A/53A
Online User Guide

Adjustable Mechanical Lumbar #12LUM



Lumbar Depth Adjustment

Type: Turn knob

Turn the knob clockwise (forward toward front of chair) to increase lumbar support, pushing the lumbar cushion forward into the back. Turn the knob counter-clockwise (backward toward back of chair) to decrease lumbar support, moving the lumbar cushion away from the back. This adjustment is made from a seated position.



< Watch our 12LUM
Online User Guide

Carmel Ratchet Back



Height Position

Type: Backrest

Grasp the backrest on both sides and lift it up. At each position, you'll hear a click. As you reach the top position, lift up & then gently drop the backrest down to the lowest starting position. This adjustment allows the backrest to be correctly positioned for differently sized individuals.



< Watch our Executive Ratchet Back
Online User Guide

Jury Base #71C-20JRY



Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Additional Features

- 360 degree swivel;
- No weight return-to-center;
- No weight return-to-max-height.